

## 焊丝用量表 订购耐磨带的磅数

← 耐磨带宽度 (英寸) →

接头直径	耐磨带直径	耐磨带重量 (磅/英寸)	0.75	1	1.5	2	2.5	3	3.5	4
4.5	4.6875	0.42	0.31	0.42	0.63	0.83	1.04	1.25	1.46	1.67
4.75	4.9375	0.44	0.33	0.44	0.66	0.88	1.10	1.32	1.54	1.76
5	5.1875	0.46	0.35	0.46	0.69	0.92	1.16	1.39	1.62	1.85
5.25	5.4375	0.48	0.36	0.48	0.73	0.97	1.21	1.45	1.70	1.94
5.5	5.6875	0.51	0.38	0.51	0.76	1.02	1.27	1.52	1.78	2.03
5.75	5.9375	0.53	0.40	0.53	0.80	1.06	1.33	1.59	1.86	2.12
6	6.1875	0.55	0.41	0.55	0.83	1.11	1.38	1.66	1.94	2.21
6.125	6.3125	0.56	0.42	0.56	0.85	1.13	1.41	1.69	1.98	2.26
6.25	6.4375	0.58	0.43	0.58	0.86	1.15	1.44	1.73	2.01	2.30
6.5	6.6875	0.60	0.45	0.60	0.90	1.20	1.50	1.80	2.09	2.39
6.625	6.8125	0.61	0.46	0.61	0.91	1.22	1.52	1.83	2.13	2.44
6.75	6.9375	0.62	0.47	0.62	0.93	1.24	1.55	1.86	2.17	2.48
7	7.1875	0.64	0.48	0.64	0.97	1.29	1.61	1.93	2.25	2.57
7.25	7.4375	0.67	0.50	0.67	1.00	1.33	1.67	2.00	2.33	2.67
8	8.1875	0.73	0.55	0.73	1.10	1.47	1.84	2.20	2.57	2.94
8.25	8.4375	0.76	0.57	0.76	1.14	1.51	1.89	2.27	2.65	3.03
8.5	8.6875	0.78	0.58	0.78	1.17	1.56	1.95	2.34	2.73	3.12